

COVER ROLLER SWIM SPA

Installation Guide



1. Position a roller rack on the outside end of the spa before the corner radius.
2. The top surface of the rack should be flush with the top of the spa.
3. Mark the position of the rack's 6 screw holes in the skirt.
4. Repeat steps 1 - 3 for the second arm on the other outside end of the spa and the third arm in the center.
5. Secure each roller rack to the spa skirt by inserting all six #10 screws tightly into the screw holes that you marked in step 3.
6. Repeat steps on other end of spa.

*** It may be required for you to insert a 2" by 4" Wood Stud behind the spas' cabinet where the position of the Cover Roller Racks are going to be screwed onto the skirt for extra support***